



Milkman COMBO


QUICKSTART GUIDE

PLEASE READ BEFORE USE

NEW LOCK

①

Combination aligned to markers




Default combination is set to 0-0-0-0

CHANGING COMBINATION


②

Check the lock release button can be pressed in



First, move cable out of the way, then use a pen or tool to push in & hold the reset button (located behind the cable return)


③



WHILST HOLDING IN THE RESET BUTTON

Rotate dials to align your desired code to the markers


④



RELEASE THE RESET BUTTON to set your combination.

Confirm your code by pressing and releasing the unlock button.

⑤




Hint: Avoid using basic codes, ie 1-2-3-4 etc!

SECURING LOCK


⑥

Have dials set to your chosen combination to fit shackle in clasp



Jumble numbers to secure lock


⑦



RELEASING LOCK


⑧

Enter your combination code and press the lock release button



Press cable recoil button to retract cable into casing. Weeeee!!

⑨



MAINTENANCE

⑩



Your MILKMAN COMBO is oil free – do not lubricate or add any liquids to the lock.